



Preparing For Delivery

Congratulations! We're excited that you have placed an order for your very own Roca. Please take a look at the steps below so that you're prepared when it arrives.

Preparing Your Network: The Roca Sorter ships with a router that will connect to your network. Here are some best practices to ensure an easy setup.

- If possible, having your router near enough to the sorter to facilitate ethernet connection is ideal. If this isn't possible, the router needs to be within wireless range of your sorter.
- The Roca sorter comes with an ethernet cable that can be used for connection via the WAN port.
- If it is necessary to connect via wireless, let your account manager know so that the Roca Team can assist with wireless setup.

Your Roca's New Home: Table, space, power, it's all important.

- Your Roca must be placed on a solid surface or sturdy table that does not shift.
- Don't use folding tables.
- Make sure the surface has room to facilitate power strips, router, and the Roca compressor pump (pump can be placed on a lower shelf).

Store Your Roca Packaging: In the event you need to move your Roca or send it to our team for diagnostics, it's important to have your packaging on hand. Please set aside space for this.

Roca Support: supportdesk@rocarobotics.com